

# AXIWI

Digital Wireless Audio System

AXIWI AT-320

User Guide



## Safety Precautions


Observe the following precautions to ensure user safety and proper use of the device.

- Avoid exposing the AXIWI AT-320 to dramatic changes in temperature or humidity. Otherwise, you may risk distortion of the product exterior or product malfunction.
- Listening to sound at high volumes may damage your hearing. Background noise, as well as continued exposure to high volume levels, can make sounds seem quieter than they actually are. Turn on the audio and check the volume before inserting anything in your ear.
- You should also pay attention to how long you listen to audio at high volume. The louder the volume, the less time required before your hearing may be affected. If you experience ringing in your ears or hear muffled speech, stop listening and have your hearing checked.
- This device is designed for short-distance communication. Use the device only in countries where the use of 2.4GHz bandwidth is permitted.
- Ensure that the device's battery charging terminal does not come in contact with an electrically charged object.
- Do not disassemble the device.
- Ensure the battery of the device is sufficiently charged before use.

## How to Turn On/Off; Master/transmitter mode:

### Turning On

1. Press the power button for about 2-3 seconds whilst pressing the volume up button.
2. When the device is booted in "master mode", the LED light remains lit continuously.



### Turning Off

1. Press the power button for about 2-3 seconds.
2. The device is turned off when all LED lights are off.



## How to Turn On/Off; follower/receiver mode

Turning On:

1. Press the power button for about 2-3 seconds.
2. When the device is booted in "follower mode", the LED light will blink and will continue to do so during the time the device is turned on.



Turning Off:

1. Press the power button for about 2-3 seconds.
2. The device is turned off when all LED lights are off.



### How to change Channels:

The AXIWI AT-320 can operate on 4 different channels or frequencies. To change channel press the S-button on the front side while pressing the volume up button.



The channel LEDs will light up in turn by the order of channels.  
(Blue -> Orange -> Red -> Green -> back to Blue -> etc.)




### \* Channel Memory Function:

When you turn off the device and turn it on again, the device will remember what channel was used before it was switched off.

## Follower Mode - How to request the "permission to speak"

1. On the device which currently is in follower mode briefly press the S-button on the front side.
2. All LED lights will light up and a beep can be heard through the headset of all devices tuned into the current channel.
3. The device is now in speak mode, allowing everyone tuned into the channel to hear the temporary speaker.




\* This function is to allow follower mode units to request the permission to speak. Permission is given on the first come first serve basis and maximum two follower mode units can get the permissions simultaneously.

Alternative software options are available to change the behavior of the permission to speak function. Please contact your supplier for more information on the available options.

## Follower Mode - How to cancel the permission to speak

1. Briefly press the S-button on the front side of the follower device currently in permission to speak mode
2. A beep will sound and the four lit LED lights will return to a single blinking LED light.



\* This function is to allow a follower mode device to cancel its permission to speak by the user himself/herself. When in normal "listening mode", only one LED for the specific channel on the unit will be blinking, instead of four lit LEDs.

**Master Mode – How to cancel the permission to speak for units in follower mode:**

1. Press the S-button on the front side of the “master mode” unit to cancel ALL the permissions to speak granted to “follower mode” units.
2. When the permissions are cancelled successfully, you can hear two beeping sounds.



\* Automatic cancellation of the permission to speak mode: When the distance between the master mode unit and the follower mode unit gets too long and communication between the two units becomes impossible, the permission to speak for the follower mode unit is automatically cancelled.



**Master Mode – How to cut off the permission to speak function for all follower units:**

1. Press and hold the volume down button for about 3-5 seconds on the master mode unit.
2. When the cut-off is made you can hear two beeping sounds through the headset of the master mode unit.



The cut-off function is to allow the master mode unit to cut off the permission to speak mode from ALL follower units. When active none of the follower units on the current channel can use the permission to speak function.

**Master Mode - How to release the cut-off of the permission to speak function:**

1. Press and hold the volume down button for about 3-5 seconds on the master mode unit.
2. When the cut-off is released you can hear one beeping sound through the headset of the master unit.



The user with the “Master” unit can switch off the Speak function of all follower units for a short moment. If so, all follower units are being switched to the same channel, but this is not being communicated. All units in “Follower” modus cannot use their speak function.

## Master Mode - Muting/unmuting the master unit:

1. To mute the master unit, press and hold the S-button for 3-5 seconds.
2. When successful the LED lights of the channels currently not in use will come on a rotational basis.



3. To unmute, again press and hold the S-button for 3-5 seconds. When only the main channel LED is on, the master unit is in normal speak mode again.

### How to Control the Volume:

Volume up:

1. Briefly press the volume up button.
2. When the volume is at its maximum level you will hear a beeping sound.



Volume Down:



1. Briefly press the volume down button.
2. When the volume is at its minimum level you will hear a beeping sound.

### Charging status display:

Status	LED-Kleur
Charging in progress	Red
Charging completed	Green



## When a malfunction is suspected

Symptoms	Actions to be taken
The battery time is shorter than the one set forth in the user manual.	<ul style="list-style-type: none"> <li>● If the device is left unattended while being exposed to low or high ambient temperatures, the battery life can be shortened.</li> <li>● Batteries are consumable products. Battery time will decrease gradually. If this occurs within the normal warranty period please contact your supplier.</li> </ul>
The device does not switch on	<ul style="list-style-type: none"> <li>● Check if the battery is charged.</li> <li>● If the symptom persists after charging, contact our service center.</li> </ul>
Interruptions occur during communication or while listening.	<ul style="list-style-type: none"> <li>● This symptom may occur if the battery is running out. Charge the unit.</li> <li>● This symptom may also occur when the device goes out of its communication range or if wireless connection is lost due to an obstacle. Try to have the follower unit closer to the master unit.</li> </ul>
There is too much static on the line during communication.	<ul style="list-style-type: none"> <li>● The range of operation for this device is about 150m for outdoor use. Indoor range will depend on obstacles such as walls, between master unit and follower unit.</li> </ul> <p>If the device goes out of range, noise may be created.</p>
I cannot acquire Permission to speak.	<ul style="list-style-type: none"> <li>● Check whether the Master allowed is not in "cut off" mode, see section 8.</li> <li>● If two follower units have already acquired permission to speak, one has to cancel their permission to speak mode before someone else to enter the channel, see section 7</li> <li>● Check if there is another unit in master mode nearby that uses the same channel.</li> </ul>
Either microphone doesn't work well or earpiece doesn't operate well at close distance.	<ul style="list-style-type: none"> <li>● You should only use an earpiece of US-type.</li> </ul> <p>If you put European earpiece into the product, It does not properly work well.</p> <p>DE</p>

## Dimension and Features

Bandwidth used	2.402~2.483[GHz]
Range of operation	+/- 250 meters
Data transmission speed	Max. 1[Mbps]
Battery time	● Max. 8 [hours] (Master mode) ● Max. 12 [hours] (Follower mode)
Battery charging time	2 [hours]
Battery type	Lithium polymer battery
Power requirement	5V DC – 800mA
Weight	39g
Wireless communication technology	PicoCast
Dimension (W x H x D)	65 x 32 x 22mm

※ The range of operation and headset service time is subject to change according to the user's operating method and service environment.

## Product Certification:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## Warranty Card

Model Name		AXIWI AT-320	Product Name	AXIWI AT-320
Date of Purchase		DD/MM/YY		Warranty Period 24 months
Purchaser	Name		Phone Number	
	Address			
Purchasing Place				

Warranty Period (for free repair service)

1) 24 months from the date of purchase

2) Our limited product warranty period applies to the following products.

Other accessories and consumables are eligible for replacement or refund within a period of two weeks from the date of receipt.

- ① AXIWI AT-320 ② AXIWI CR-001 ③ AXIWI AT-110 ④ AXIWI CR-003

### 3) Exceptions

Even during the warranty period, the following may be subject to predetermined repair charge or unavoidable paid replacement.

Product malfunction caused by user mistake or negligence during product use.

- ② Product malfunction caused by disassembly or modification of the product by the user.
- ③ Product damage or malfunction caused by a shock.
- ④ Corrosion caused by flooding or contamination by foreign substances.
- ⑤ Product malfunction caused by contact with a device not provided by our company.
- ⑥ Unidentifiable product number because of damaged label.
- ⑦ Product malfunction caused by a natural disaster
- ⑧ Other cases where there is a recognizable user fault.

### **Rules for Product Replacement**

The product may be eligible for replacement if

- 1) In case the product to be repaired is found to be different from the purchased one;
- 2) In case the product to be repaired is found to be damaged;
- 3) In case the same malfunction occurs after three repairs for the same symptom (within the warranty period);
- 4) In case a malfunction occurs after four repairs for different type of malfunctions;
- 5) In case the product to be repaired is lost.

### **Rules for Refunds**

- 1) In case the product to be repaired is found to be different from the purchased one.
- 2) A material product defect is found during product use within 10 days from the date of purchase.
- 3) Refunds can be made only at the place of purchase. Please call the place where you purchased the product for refund.
- 4) You will not be eligible for refund if you don't have the receipt or the product warranty card as proof of purchase.

### **Cautions**

- 1) Product return will not be processed if you find the product value to be significantly lower than that of a newer model after opening the product package.
- 2) Please note that in the absence of an accurate checking of product specification at your end, you will be responsible for the problems in product usage.

Main office :  
Axitour B.V.  
Lübeck 5  
2993 LK BARENDRECHT  
The Netherlands  
Tel: +31 180 691 400  
E info@axitour.eu  
/ info@axiwi.com  
www. axitour.com / www. axiwi.com

Axitour Scandinavia  
Furuveien 5C  
1450 Nesoddtangen  
Norway  
E info@axitour.com  
T +47 4634 4505  
E info@axitour.com / I [www.axitour.no](http://www.axitour.no)

AXIWI® is a registered trademark of Axitour B.V.